


INSTRUCTIONS

APPLICATION: 1999-06 TOYOTA TUNDRA EXTENDED CAB 2004-06 TOYOTA TUNDRA DOUBLE CAB


STEP BAR ASSEMBLIES

202006-2



ITEM	QTY	CONTENTS -	TOOLS -		
1,2 3,4 5,6 7 8 9 10 11 12 13	2 2 2 1 1 2 6 8 8	STEP BAR, PASSENGER (1) AND DRIVER (2) FRONT BRACKET, PASSENGER (3) AND DRIVER (4) REAR BRACKET, PASSENGER (5) AND DRIVER (6) FRONT MOUNT TAB ASSEMBLY, PASSENGER FRONT MOUNT TAB ASSEMBLY, DRIVER SPACER WASHER 1/2-13 X 1.75" HEX HEAD BOLT 1/2" FLAT WASHER 1/2" LOCK WASHER 1/2-13 HEX NUT	3/4" SOCKET 3/4" WRENC 6" EXTENSIO RATCHET TORQUE WE	H ON	

- STEP 1. Remove the contents from box and check for damage. Verify all parts are present. Read instructions completely before beginning.
- STEP 2. Locate the rectangular holes in frame towards the front of the vehicle. Insert front mount tab assemblies into the hole from the inside of frame. Attach front brackets as shown. Hand tighten.
- STEP 3. Attach rear brackets as shown. Hand tighten. **NOTE:** Place the spacer washer under the head of the hex head bolt and insert through frame from the inside of frame.
 - STEP 4. Attach step bars as shown. Hand tighten.
 - STEP 5. Make sure step bar and brackets are properly aligned with vehicle and tighten fasteners. Recommended torque value is 64 Ft. Lbs. for 1/2" fasteners.



FINISH PROTECTION

Aries products have a high quality finish that must be cared for like any other exposed finish on the vehicle. Protect the finish with a non-abrasive au tomotive wax, (e.g. Pure Carnauba) on a regular basis. The use of any soap, polish or wax that contains an abrasive is detrimental, as the compounds scratch the finish and open it to corrosion.