



PART# 15600TW
INSTRUCTION SHEET

JEEP WRANGLER TOW HOOK
FITS -15600 BUMPER

PARTS-

- 1- (1) TOW HOOK –UNIVERSAL PASSENGER/DRIVER
- 2- (2) 12MM X 45MM BOLT
- 3- (2) 12MM FLAT WASHER
- 4- (2) 12MM SPLIT WASHER

STEP ONE: MAKE SURE ALL CONTENTS ARE WITHIN PACKAGE.

STEP TWO: LINE UP THE TOW HOOK WITH THE EXISTING HOLES ON THE ARIES REPLACEMENT BUMPER. TOW HOOK SHOULD BE FACED OUTWARD. SEE FIG 1.

STEP THREE: INSTALL TOW HOOK USING THE 16MM HARDWARE, AND TIGHTEN SECURE. SEE FIG. 2.

FIGURE 1



FIGURE 2

