



PRO COMP SUSPENSION, Inc. Chula Vista, CA USA

Ph:(619) 216-1444 ● Fax:(619) 216-1474 ● E-Mail: tech@explorerprocomp.com ● Website: www.explorerprocomp.com

INSTALLATION INSTRUCTIONS:

Part # 55415 Jeep Wrangler TJ 1.5 Spacer Kit

⇒ **PLEASE READ ALL INSTRUCTIONS FROM START TO FINISH BEFORE YOU BEGIN INSTALLATION.**

Front Disassembly:

- 1) Block rear tires and raise front of vehicle with floor jack or other suitable means.
- 2) Support chassis with jack stands behind front lower control arm mounts.
- 3) Remove wheels, spring retaining clips and front shocks.
- 4) Lower front axle and remove coils.
- 5) Remove bump stops by pulling down on rubber piece. This will access bolt that retains bump stop mounting cup.
- 6) Remove cup and rubber spring pad at the top of spring tower.

Front Assembly:

- 1) Slide aluminum spacer **#4001** onto bump stop mount.
- 2) Install spring pad below spacer.
- 3) Reinstall bump stop cup and rubber bump stop.
- 4) Install coils, shocks, coil retaining clips and tires.
- 5) Lower vehicle to ground.

Rear Disassembly:

- 1) Block front tires and raise rear of vehicle. Support chassis with jack stands in front of rear control arm mounts.
- 2) Remove tires.
- 3) Remove lower shock bolts and lower rear axle.

Rear Assembly:

- 1) Install aluminum spacer **#4004** on spring pad located on rear axle tube.
- 2) Install rear coils and raise axle to install lower shock bolts.
- 3) Install tires and lower to ground.
- 4) Check all hardware for tightness.