



2360 Boswell Road
Chula Vista, CA 91914
Phone: 619.216.1444
Fax: 619.216.1474
E-Mail: tech@explorerprocomp.com

PRO COMP SUSPENSION

Suspension Systems that Work!

**INSTALLATION
INSTRUCTIONS**

**Part # 66164
Front Bumper
Fits 76-99 Jeep CJ,
Wrangler YJ/TJ**

HARDWARE KIT:

2 ea. 1/4" spacers

Thank you for choosing Pro Comp Suspension. Your new bumper is designed to provide years of satisfaction if properly installed and maintained.

CAUTION: BEFORE BEGINNING INSTALLATION, READ INSTRUCTIONS CAREFULLY AND COMPLETELY.

WARNING: BEFORE TIGHTENING BOLTS OR DRILLING WHERE REQUIRED, CHECK TO MAKE SURE THERE ARE NO OBSTRUCTIONS SUCH AS BRAKE, FUEL, OR ELECTRICAL LINES THAT MIGHT BE DAMAGED OR DESTROYED. SIMPLE RE-ROUTING OF THESE LINES CAN PREVENT COSTLY OR DANGEROUS RESULTS.

STEP 1: Remove factory front bumper bolts, but do not discard as they are re-used for installation of your new Pro Comp front bumper.

STEP 2: Attach and secure new front bumper to frame utilizing same holes as those used by factory bumper as well as factory screws. *NOTE: CJ models require use of 1/4" spacers (included in parts kit) on bottom of frame between frame and lower bumper mounting brackets on bumper.*

STEP 3: Tighten bolts securely. Installation is complete.

