PRO COMP SUSPENSION

2360 Boswell Road Chula Vista, CA 91914 Phone 619.216.1444 Fax 619.216.1474

E-Mail tech@explorerprocomp.com

Suspension Systems that Work!

Bill of Materials:

 90-6493
 HARDWARE PACK: DRIVESHAFT
 1

 .120C600HCS1Y
 12mm- 1.75 X 60mm 10.9 HEX BOLT
 4

 73-01200830
 12mm SAE FLAT WASHER
 4

90-4107 DRIVESHAFT SPACER 1

INSTALLATION INSTRUCTIONS:

1. Slip in new aluminum Rear driveshaft spacer (PN 90-4107) and fasten with supplied 12mm X 60mm Bolts and washers from hardware pack (PN 90-6493). Be sure to use thread locker on these bolts. SEE ILLUSTRATION 1. Rotate driveshaft to check for binding. If it binds the driveshaft must be clearanced by a qualified driveline shop.

NOTE: The use of this driveshaft spacer is intended for light usage only. If the intended usage is for high speed off road, this spacer should not be installed. The factory rear driveshaft should be lengthened by a qualified driveline shop.

IMPORTANT!: Fully cycle the rear suspension and check for drive-shaft plunge. If the driveshaft is too long it will destroy the transfer case. Pro Comp takes NO responsibility for damage caused as a result of the installation of this kit.

PART# 90-4107B Ford F-150 Rear Driveshaft Spacer

