



## INSTALLATION INSTRUCTIONS

# 2018 JEEP® WRANGLER JL® ADAPT HOOD MOUNT



PRODUCT INCLUDES:

(2) Mount #41665

\* LIGHTS SOLD SEPARATELY

**\*THIS MOUNT FITS THE FOLLOWING LIGHTS:**

**(1) 20" Adapt®**

### **IMPORTANT**

**THANK YOU FOR PURCHASING RIGID PRODUCTS FOR YOUR VEHICLE.**

Please read through all of these Instructions and tips before proceeding with the installation.

We do our best to provide a simple installation process for all applications however a professional installation is always recommended.

**Always disconnect any power sources connected to your vehicle  
before servicing fuses or electrical systems.**

## STEP 1

Begin installation by removing factory Torx hood hinge bolts as shown.

See Figure 1

FIGURE 1



## STEP 2

Pre-install brackets to light as shown. Note: Slotted adjustment holes are located at the rearward bolt holes on the Adapt light.

See Figure 2

FIGURE 2



## STEP 3

Install assembly onto vehicle as one unit with the provided M8 button head screws and washers, ensuring the paint protection gaskets are laid into place underneath the brackets.

See Figure 3

FIGURE 3



## STEP 4

Wire lamp as specified in lamp instructions. Your installation is now complete!





**Wiring: Wire your lights according to the instructions included with the light.  
Take care to avoid any heat sources and sharp or abrasive surfaces.**

**Your installation is now complete.  
Welcome to the Rigid Nation!**

---

## **WARRANTY INFORMATION**

For warranty information, visit [www.rigidindustries.com/about/warranty](http://www.rigidindustries.com/about/warranty)

779 N Colorado St, Gilbert, AZ 85233 • 855-760-5337  
[www.rigidindustries.com](http://www.rigidindustries.com)

Adapt, RIGID, and Rigid Industries are registered and/or common law marks owned by JST Performance, LLC,  
a Delaware limited liability company d/b/a Rigid Industries.

11-12922-A