



## 1994 Dodge Dually Mud Flap Installation Instructions

1. Attach the Mud Flap to the bracket using three 5/16" bolts, flat washers, lock washers and nuts. The slots in the flap will line up with the three slots on the bracket. Aluminum material faces toward the rear of the truck.
2. A hole has been provided at the end of the bracket for mounting to the pinch weld. A hole is also located near the center of the bracket. Using these two holes as guides and an 11/32" drill bit, drill thru the pinch weld, and drill thru the rear wheel well. Using the 5/16" fasteners provided, attach the bracket in the wheel well.
3. Repeat this procedure on the other side of the truck.



Lund International

800-241-7219 • Visit us at [lundinternational.com](http://lundinternational.com)

© 2012 Lund International, Inc. All rights reserved.

Lund® and the Lund® logo are trademarks of Lund International, Inc.

