



# INSTALLATION INSTRUCTIONS

APPLICATION:

2007-2013 Chevy 1500

AUTOMOTIVE PRODUCTS, PART NUMBER:

58-250705/58-25070R

CONTENT			
ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	2	TAG LIGHTS	15 MM SOCKET
2	4	1/2" x 1 1/2" BOLT	18 MM SOCKET
3	4	1/2" NUT	21 MM SOCKET
			3/4" SOCKET
			3/4" WRENCH
			RATCHET WITH EXTENSIONS

## REMOVAL

1. Disconnect the tag lights and the trailer plug harness
2. Remove the 6 bolts that hold the bumper to the frame
3. Remove the bumper from the truck

## INSTALLATION

1. Install the tag lights in bumper
2. Align the bumper with the frame
3. Install the 4 - 1/2" x 1 1/2" bolts and 1/2" nuts
4. Reinstall the 2 bolts that attach the receiver to the frame
5. Adjust the bumper to achieve proper alignment
6. Tighten all hardware



Westin Automotive Products, Inc.  
320 W. Covina Blvd  
San Dimas, Ca. 91773

Thank You for choosing Westin products  
For Additional installation assistance please call  
Customer service (800) 793-7846