



INSTALLATION INSTRUCTIONS

APPLICATION:

2014-2015 Toyota Tundra

AUTOMOTIVE PRODUCTS, PART NUMBER:

58-271305/58-27130R

CONTENT			
ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	2	TAG LIGHTS	12MM SOCKET
2	4	1/2" x 1 1/2" BOLT	19MM SOCKET
3	4	1/2" NUT	3/4" SOCKET
			3/4" WRENCH
			RATCHET
REMOVAL			
<ol style="list-style-type: none"> 1. Remove the license plate 2. Remove the plastic bumper cover 3. Disconnect the factory tag lights 4. Remove the bolts that hold the bumper to the receiver hitch 5. Remove the bumper from the truck 6. Remove the 4 bolts that attach the receiver to the truck 			
INSTALLATION			
<ol style="list-style-type: none"> 1. Attach intermediate brackets to frame using the factory hardware 2. Align the bumper with the truck and intermediate brackets, then loosely install the 4 - 1/2" x 1 1/2" and 1/2" nuts 3. Position the bumper to achieve proper alignment 4. Tighten all hardware 			



Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773

Thank You for choosing Westin products
For Additional installation assistance please call
Customer service (800) 793-7846