



# INSTALLATION INSTRUCTIONS

APPLICATION:

2009-2015 Dodge 1500

AUTOMOTIVE PRODUCTS, PART NUMBER:

58-260905/58-26090R

CONTENT			
ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	2	TAG LIGHTS	15MM SOCKET
2	4	7/16" x 1 1/2" BOLT	3/4" SOCKET
3	4	7/16" NUT	3/4" WRENCH
			RATCHET
REMOVAL			
<ol style="list-style-type: none"> <li>1. Unhook the factory tag lights</li> <li>2. While supporting the bumper, remove the 6 bolts that attach the bumper to the frame</li> <li>3. Remove the bumper from the truck</li> </ol>			
INSTALLATION			
<ol style="list-style-type: none"> <li>1. Align the mounts in the bumper with the frame brackets and slide the bumper onto the truck</li> <li>2. Install the 4 - 7/16" x 1 1/2" bolts and 7/16" nuts through the frame brackets and bumper mounts</li> <li>3. Adjust the bumper to achieve proper alignment</li> <li>4. Tighten all hardware</li> <li>5. Install the supplied tag lights and connect the wire to the hot (red) wire on the factory tag light harness</li> </ol>			



Westin Automotive Products, Inc.  
320 W. Covina Blvd  
San Dimas, Ca. 91773

Thank You for choosing Westin products  
For Additional installation assistance please call  
Customer service (800) 793-7846