



AIRGUARD / ULTRAGUARD

Non Drill BUG DEFLECTOR

Installation Instructions

- 1) Thoroughly clean front hood area. Open hood.
- 2) Place the bugshield in position, ensuring it is centered and fits tight against the hood.
- 3) Carefully slide the clips over the bugshields and sheet metal of hood, **MAKING SURE** the **BARBED** side of the clips slides into the plastic slot.
- 4) Slowly close the hood and check for sufficient clearance between the bugshield and the grill. **DO NOT HOLD BUGSHIELD WHEN CLOSING THE HOOD.**
- 5) **DO NOT ATTACH THE CLEAR BUMP-ONS TO THE BUGSHIELD. DOING SO WILL RESULT IN PAINT DAMAGE THAT WILL NOT BE COVERED BY THE WARRANTY.**
With the alcohol pad provided clean 6-8 areas behind the bugshield large enough to affix the bump-on.
- 6) Starting on either end of the shield gently pull the bugshield away from the hood and place the bump-on between the hood and the bugshield. **BE SURE TO INSTALL ON TO THE HOOD.**
Now go to the opposite end of the shield and do the same thing.
- 7) Simulate the wind by gently pushing on the bugshield. Where the shield touches the hood place a bump-on there. Go to the opposite side and do the same thing again.
Continue until you are certain that the bump-on are positioned to keep the bugshield from contacting the hood.
- 8) Close hood and tell all your friends about your **FANTASTIC** new shield from **WADE**.

Cleaning Instructions:

Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised