INSTALLATION GUIDE: HYLUX 2A88EU BALLAST




WARNING: By reading this document, I agree it is only to be used as an educational guide. The Retrofit Source makes no guarantee on any finished results, nor are they to be held responsible for any damage, misuse, or personal injuries. Use at your own risk. If you are unable to clearly understand and adapt the information below to your own application, professional installation is recommended.

PACKAGE CONTENTS:



1x Hylux 2A88EU Ballast

BALLAST MOUNTING:



We recommend ensuring the wiring exits the ballast at the bottom to minimize the risk of water ingress.

BALLAST WIRING:



Plug the 9006 input into the ballast output on the harness of your choice / application.



Plug the AMP-style outputs into the bulb connections of your choice.



Fix the ring terminal to the Battery Negative (-) terminal or a bare metal chassis ground.

